

Cut Charts

BNCQ

Operating Frequency	Inches	cm
VHF		
136 MHz	20	50.8
140 MHz	19	48.3
146 MHz	18	45.7
150 MHz	17 5/8	44.8
156 MHz	17	43.2
160 MHz	16 1/2	41.9
165 MHz	15 3/4	40.0
170 MHz	15	38.1
175 MHz	14 7/8	37.8
180 MHz	14 5/8	37.1
185 MHz	14 1/2	36.8
190 MHz	14	35.6
195 MHz	13 5/8	34.6
200 MHz	13	33.0
205 MHz	12 7/8	32.7
210 MHz	12 3/4	32.4
215 MHz	12 5/8	32.1
220 MHz	12 1/2	31.8
225 MHz	11 7/8	30.2
UHF		
405 MHz	6 1/4	15.9
420 MHz	6 1/8	15.6
430 MHz	6	15.2
440 MHz	5 7/8	14.9
450 MHz	5 3/4	14.6
460 MHz	5 1/2	14.0
470 MHz	5 1/4	13.3
480 MHz	5 1/8	13.0
490 MHz	5	12.7
500 MHz	4 7/8	12.4